



## *MM23xx2D Series*

### *USER MANUAL*

MM23002D

MM23012D

MM23102D

MM23112D

MM23202D

MM23212D

MM23402D

MM23412D

Dear Valued Consumer:

Congratulations on your purchase of the **MM23xx2D Series** drive. This User Manual was created for you to get the most out of your new device and assist with the initial setup. Please visit [www.minarikdrives.com](http://www.minarikdrives.com) to learn more about our other drives.

Thank you for choosing **Minarik Drives**!

© 2013 Minarik Drives. All rights reserved.

No part of this document may be reproduced or transmitted in any form without written permission from Minarik Drives. The information and technical data in this document are subject to change without notice. Minarik Drives makes no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. Minarik Drives assumes no responsibility for any errors that may appear in this document and makes no commitment to update or to keep current the information in this document.

# Safety First!

## SAFETY WARNINGS



Text in gray boxes denote important safety tips or warnings. Please read these instructions carefully before performing any of the procedures contained in this manual.

- DO NOT INSTALL, REMOVE, OR REWIRE THIS EQUIPMENT WITH POWER APPLIED. Have a qualified electrical technician install, adjust and service this equipment. Follow the National Electrical Code and all other applicable electrical and safety codes, including the provisions of the Occupational Safety and Health Act (OSHA), when installing equipment.
- Reduce the chance of an electrical fire, shock, or explosion by using proper grounding techniques, over-current protection, thermal protection, and enclosure. Follow sound maintenance procedures.



It is possible for a drive to run at full speed as a result of a component failure. Minarik Drives strongly recommends the installation of a master switch in the main power input to stop the drive in an emergency.

Circuit potentials are at 115 VAC or 230 VAC above earth ground. Avoid direct contact with the printed circuit board or with circuit elements to prevent the risk of serious injury or fatality. Use a non-metallic screwdriver for adjusting the calibration trim pots. Use approved personal protective equipment and insulated tools if working on this drive with power applied.

## Table of Contents

<b>Section 1. Specifications .....</b>	<b>1</b>
<b>Section 2. Dimensions.....</b>	<b>3</b>
<b>Section 3. Installation .....</b>	<b>9</b>
Heat Sinking .....	9
Mounting .....	10
Chassis .....	10
Speed Adjust Potentiometer .....	11
NEMA 1 .....	12
NEMA 4X .....	13
Wiring .....	14
Shielding Guidelines.....	15
Line Fusing .....	16
Connections.....	18
Power Inputs .....	18
Motor.....	18
Speed Adjust Potentiometer.....	19
Analog Input Signal .....	20
<b>Section 4. Operation.....</b>	<b>23</b>
Before Applying Power .....	23
Select Switches .....	24
Input Voltage Select (SW501, SW502) .....	24
Armature Voltage Select (SW503) .....	24
Operation Modes .....	25
Speed Mode .....	25
Torque Mode .....	25
Startup .....	27
MM23002D and MM23012D .....	27
MM23102D, MM23112D, MM23402D, and MM23412D .....	27
MM23202D and MM23212D .....	28
Starting and Stopping Methods .....	29

Line Starting and Stopping .....	29
Dynamic Braking .....	30
Inhibit Terminals .....	32
Decelerating to Minimum Speed .....	34
<b>Section 5. Calibration .....</b>	<b>35</b>
Minimum Speed (MIN SPD) .....	36
Maximum Speed (MAX SPD) .....	36
Torque (TORQUE) .....	37
IR Compensation (IR COMP) .....	38
Acceleration (ACCEL) .....	40
Deceleration (DECEL) .....	40
Torque Mode Calibration .....	41
<b>Section 6. Application Notes .....</b>	<b>42</b>
Multiple Fixed Speeds .....	42
Adjustable Speeds Using Potentiometers In Series .....	43
Independent Adjustable Speeds .....	44
RUN/JOG Switch - Inhibit Connection .....	45
RUN/JOG Switch - Potentiometer Connection .....	46
Leader-Follower Application .....	47
Single Speed Potentiometer Control Of Multiple Drives .....	48
Reversing .....	49
<b>Section 7. Diagnostic LEDs .....</b>	<b>50</b>
<b>Section 8. Troubleshooting .....</b>	<b>51</b>
Before Troubleshooting .....	51
<b>Section 9. Block Diagrams .....</b>	<b>54</b>
<b>Section 10. Accessories &amp; Replacement Parts .....</b>	<b>57</b>
<b>Section 11. CE .....</b>	<b>58</b>
<b>Unconditional Warranty .....</b>	<b>61</b>

## List of Tables

---

Table 1	Recommended Line Fuse Sizes .....	17
Table 2	Short Circuit Current Ratings .....	17
Table 3	Minimum Recommended Dynamic Brake Resistor Values ...	31

## List of Figures

Figure 1	MM23002D and MM23012D Dimensions.....	3
Figure 2	MM23102D and MM23112D Dimensions.....	4
Figure 3	MM23202D and MM23212D Dimensions.....	5
Figure 4	MM23402D and MM23412D Dimensions.....	6
Figure 5	223-0159 Dimensions.....	7
Figure 6	223-0174 Dimensions.....	8
Figure 7	Speed Adjust Potentiometer .....	11
Figure 8	Analog Input Signal Connections.....	20
Figure 9	Chassis Drive Connections .....	21
Figure 10	Cased Drive Connections .....	22
Figure 11	Select Switches .....	24
Figure 12	J503 SPEED/TORQUE Jumper Settings.....	26
Figure 13	J503 SPEED/TORQUE Jumper Location.....	27
Figure 14	Dynamic Brake Wiring with Normally Open Inhibit.....	31
Figure 15	Inhibit Terminals .....	32
Figure 16	Inhibit Personality Configuration .....	33
Figure 17	Run/Decelerate to Minimum Speed Switch.....	34
Figure 18	Recommended TORQUE and IR COMP Settings .....	39
Figure 19	Multiple Fixed Speeds .....	42
Figure 20	Adjustable Speeds Using Potentiometers in Series.....	43
Figure 21	Independent Adjustable Speeds.....	44
Figure 22	RUN/JOG Switch - Connection to Inhibit Plug with Normally Open Inhibit set for Zero Mode .....	45
Figure 23	RUN/JOG Switch - Connection to Speed Adjust Potentiometer .....	46
Figure 24	Leader-Follower Application .....	47
Figure 25	Single Speed Potentiometer Control of Multiple Drives.....	48
Figure 26	Reversing Circuit Wiring .....	49

Figure 27	Diagnostic LED Locations .....	50
Figure 28	MM23xx2D Series Block Diagram .....	54
Figure 29	MM23102D, MM23112D, MM23402D, and MM23412D Terminal Block Connections .....	55
Figure 30	MM23402D and MM23412D Terminal Block Connections...	56

## Section 1. Specifications

<i>Model</i>	<i>Maximum Armature Current (ADC)</i>	<i>HP Range with 90 VDC Motor</i>	<i>HP Range with 180 VDC Motor</i>	<i>Enclosure</i>
MM23012D	1.5	1/20 - 1/8	1/10 - 1/4	Chassis
MM23112D				NEMA 1
MM23212D				NEMA 1
MM23412D				NEMA 4X
MM23002D*	10.0	1/8 - 1	1/4 - 2	Chassis
MM23102D**				NEMA 1
MM23202D**				NEMA 1
MM23402D				NEMA 4X

\* Heat sink kit part number 223-0159 must be used when the continuous current output is over 5 amps.

\*\* Heat sink kit part number 223-0174 must be used when the continuous current output is over 5 amps.

<b>AC Line Voltage</b>	115/230 VAC $\pm$ 10% 50/60 Hz, single phase
<b>DC Armature Voltage</b>	
with 115 VAC Line Voltage	0 - 90 VDC
with 230 VAC Line Voltage	0 - 180 VDC
<b>Acceleration Time Range</b>	0.5 - 17 seconds
<b>Deceleration Time Range</b>	coast to a stop - 25 seconds
<b>Analog Input Range</b> (signal must be isolated; S1 to S2)	0 - 2.5 VDC
<b>Input Impedance (S1 to S2)</b>	>100K ohms
<b>Form Factor</b>	1.37 at base speed
<b>Load Regulation</b>	1% base speed or better
<b>Speed Range</b>	60:1

## MM23xx2D Series

---

**Vibration**

0.5G maximum (0 - 50 Hz)

0.1G maximum (&gt; 50 Hz)

---

**Safety Certifications**

UL/cUL Listed Equipment, File # E132235

CSA Certified Component, File # LR41380

---


**Ambient Temperature Range***Chassis Drive*

10°C - 55°C

*Cased Drive*


10°C - 40°C

## Section 2. Dimensions




ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 1. MM23002D and MM23012D Dimensions





ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 2. MM23102D and MM23112D Dimensions




ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 3. MM23202D and MM23212D Dimensions




ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 4. MM23402D and MM23412D Dimensions



ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 5. 223-0159 Dimensions



ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 6. 223-0174 Dimensions

## Section 3. Installation



**Do not install, rewire, or remove this control with input power applied.** Failure to heed this warning may result in fire, explosion, or serious injury. Make sure you read and understand the Safety Precautions on page i before attempting to install this product.

### Heat Sinking

#### Chassis

Model MM23002D requires an additional heat sink when the continuous armature current is above 5 amps. Use Minarik Drives heat sink kit part number 223-0159. All other chassis drives have sufficient heat sinking in their basic configuration. Use a thermally conductive heat sink compound (such as Dow Corning® 340 Heat Sink Compound) between the chassis and the heat sink surface for optimum heat transfer.

#### NEMA 1

Models MM23102D and MM23202D require an additional heat sink when the continuous armature current is above 5 amps. Use Minarik Drives heat sink kit part number 223-0174. All other NEMA 1 drives have sufficient heat sinking in their basic configuration. Use a thermally conductive heat sink compound (such as Dow Corning® 340 Heat Sink Compound) between the chassis and the heat sink surface for optimum heat transfer.

#### NEMA 4X

All NEMA 4X models come with the heat sink already attached. Therefore, all NEMA 4X drives have sufficient heat sinking in their basic configuration.

### Mounting

#### Chassis

- Drive components are sensitive to electrostatic discharge. Avoid direct contact with the circuit board. Hold the drive by the chassis or heat sink only.
- Protect the drive from dirt, moisture, and accidental contact.
- Provide sufficient room for access to the terminals and calibration trim pots.
- Mount the drive away from heat sources. Operate the drive within the specified ambient operating temperature range.
- Prevent loose connections by avoiding excessive vibration of the drive.
- Mount the drive with its board in either a horizontal or vertical plane. Eight 0.19" (5 mm) wide slots in the chassis accept #8 pan head screws. Fasten either the large base or the narrow flange of the chassis to the subplate.
- The chassis should be earth grounded. Use a star washer beneath the head of at least one of the mounting screws to penetrate the anodized surface and to reach bare metal.

## Speed Adjust Potentiometer



Be sure that the potentiometer tabs do not make contact with the potentiometer's body. Grounding the input will cause damage to the drive.

If using a remote potentiometer with a chassis drive, mount the speed adjust potentiometer through a 0.38 in. (10 mm) hole with the hardware provided (Figure 7). Install the circular insulating disk between the panel and the 10K ohm speed adjust potentiometer.

Twist the speed adjust potentiometer wire to avoid picking up unwanted electrical noise. If the speed adjust potentiometer wires are longer than 18 in. (46 cm), use shielded cable. Keep the speed adjust potentiometer wires separate from power leads (L1, L2, A1, A2).




Figure 7. Speed Adjust Potentiometer

### Mounting (NEMA 1 Enclosures)

NEMA 1 cased drives come with two 0.88 inch (22 mm) conduit holes at the bottom of the case. The units may be vertically wall mounted or horizontally bench mounted using the three keyholes on the back of the case.

1. For access to the keyholes and the terminal strip, remove the two screws from the front of the case by turning them counterclockwise. Grasp the front cover and pull it straight out.
2. Install the mounting screws in the three keyholes.
3. Set the POWER switch to the OFF position before applying the AC line voltage.
4. Install conduit hardware through the conduit holes at the bottom of the case. Connect external wiring to the terminal block.
5. Reinstall the front cover. Avoid pinching any wires between the front cover and the case.
6. Reinstall the two screws on the front cover. Turn the screws clockwise to tighten.

## **Mounting (NEMA 4X Enclosures)**

NEMA 4X cased drives come with two 0.88 inch (22 mm) conduit knockout holes at the bottom of the case. The units may be vertically wall mounted using the four 0.19 inch (5 mm) slotted holes on the attached heat sink. For motor loads less than 5 ADC, the drive may be bench mounted horizontally or operated without mounting.

1. Install the mounting screws.
2. For access to the terminal strip, turn the slotted screw on the front cover counterclockwise until it is free from the case. The right side of the cover is hinged to the case. Pull the slotted screw to open the case.
3. Carefully remove the conduit knockouts by tapping them into the case and twisting them off with pliers.
4. Set the POWER switch to the OFF position before applying the AC line voltage.
5. Install conduit hardware through the 0.88 inch (22 mm) knockout holes. Connect external wiring to the terminal block.
6. Grasp the slotted screw and tilt the front cover back into place. Avoid pinching any wires between the front cover and the case.
7. Turn the slotted screw clockwise until tight to secure the front cover.

### Wiring



**Do not install, rewire, or remove this control with input power applied.** Failure to heed this warning may result in fire, explosion, or serious injury.

Circuit potentials are at 115 or 230 VAC above ground. To prevent the risk of injury or fatality, avoid direct contact with the printed circuit board or with circuit elements.

Do not disconnect any of the motor leads from the drive unless power is removed or the drive is disabled. Opening any one motor lead while the drive is running may destroy the drive.

This product does not have internal solid state motor overload protection. It does not contain speed-sensitive overload protection, thermal memory retention or provisions to receive and act upon signal from remote devices for over temperature protection. If motor over protection is needed in the end-use product, it needs to be provided by additional equipment in accordance with NEC standards.

- Use 18 - 24 AWG wire for logic wiring. Use 14 - 16 AWG wire for AC line and motor wiring.

## Shielding Guidelines



Under no circumstances should power and logic level leads be bundled together. Induced voltage can cause unpredictable behavior in any electronic device, including motor controls.

As a general rule, Minarik Drives recommends shielding of all conductors. If it is not practical to shield power conductors, it is recommended to shield all logic-level leads. If shielding of all logic-level leads is not practical, the user should twist all logic leads with themselves to minimize induced noise.

It may be necessary to earth ground the shielded cable. If noise is produced by devices other than the drive, ground the shield at the drive end. If noise is generated by a device on the drive, ground the shield at the end away from the drive. Do not ground both ends of the shield.

If the drive continues to pick up noise after grounding the shield, it may be necessary to add AC line filtering devices, or to mount the drive in a less noisy environment.

Logic wires from other input devices, such as motion controllers and PLL velocity controllers, must be separated from power lines in the same manner as the logic I/O on this drive.

### Line Fusing

Chassis drives should be fused for protection. Use fast acting fuses rated for 250 VAC or higher and 150% of maximum armature current. Fuse HOT L1 only when the line voltage is 115 VAC. Fuse both L1 and L2 when the line voltage is 230 VAC. Table 1 on page 17 lists the recommended line fuse sizes.

Cased models come with preinstalled fuses. Models MM23102D, MM23202D and MM23402D are preinstalled with 15 amp fuses. Models MM23112D, MM23212D and MM23412D are preinstalled with 3 amp fuses.

Preinstalled line fuses are rated for maximum horsepower. If the horsepower rating of the motor being used is less than the maximum horsepower rating of the drive, the line fuse may have to be replaced with a lower rated one. Fuses should be rated for 250 VAC or higher and approximately 150% of the maximum armature current. Refer to Table 1 on page 17 to install a lower rated fuse.

Refer to Table 2 on page 17 for Short Circuit Current Ratings (SCCR).

Table 1. Recommended Line Fuse Sizes

<i>90 VDC Motor Horsepower</i>	<i>180 VDC Motor Horsepower</i>	<i>Maximum DC Armature Current (amps)</i>	<i>AC Line Fuse Size (amps)</i>
<i>1/20</i>	<i>1/10</i>	<i>0.5</i>	<i>1</i>
<i>1/15</i>	<i>1/8</i>	<i>0.8</i>	<i>1.5</i>
<i>1/8</i>	<i>1/4</i>	<i>1.5</i>	<i>3</i>
<i>1/6</i>	<i>1/3</i>	<i>1.7</i>	<i>3</i>
<i>1/4</i>	<i>1/2</i>	<i>2.5</i>	<i>5</i>
<i>1/3</i>	<i>3/4</i>	<i>3.5</i>	<i>8</i>
<i>1/2</i>	<i>1</i>	<i>5.0</i>	<i>10</i>
<i>3/4</i>	<i>1 1/2</i>	<i>7.5</i>	<i>15</i>
<i>1</i>	<i>2</i>	<i>10</i>	<i>15</i>

Minarik Drives offers fuse kits. See Section 10: Accessories and Replacement Parts for fuse kit part numbers.

Table 2. Short Circuit Current Ratings

<b>Drive Model</b>	<b>Short Circuit Current Rating</b>		<b>Types of Branch Circuit Protection</b>		<b>Maximum Rating of Overcurrent Protection</b>
	<b>Maximum Current, kA</b>	<b>Maximum Voltage, V</b>			
MM23002D	10,000	240 V	Non-time Delay K5 Fuse	Inverse Time Circuit Breaker	30 A
MM23102D					
MM23202D					
MM23402D					

### Connections



**Do not connect this equipment with power applied.** Failure to heed this warning may result in fire, explosion, or serious injury.

**Minarik Drives strongly recommends the installation of a master power switch in the voltage input line, as shown in Figure 9 (page 21).** The switch contacts should be rated at a minimum of 200% of motor nameplate current and 250 volts. This power switch is provided with NEMA 1 and NEMA 4X models.

### Power Input

For chassis models, connect the AC line power leads to terminals L1 and L2. Minarik Drives recommends the use of a single-throw, double-pole master power switch. The switch should be rated at a minimum of 250 volts and 200% of motor current. Refer to Figure 9 on page 21.

For enclosed models, connect the AC line power leads to screw terminals 1 (L1) and 2 (L2 115) if using a 115 VAC line or to terminals 1 (L1) and 3 (L2 230) if using a 230 VAC line. Refer to Figure 10 on page 22.

### Motor

Drives supply motor armature voltage from A1 and A2 terminals. It is assumed throughout this manual that, when A1 is positive with respect to A2, the motor will rotate clockwise (CW) while looking at the output shaft protruding from the front of the motor. If the motor does not spin in the desired direction, remove power and reverse the A1 and A2 connections.

For chassis models, connect a DC motor to terminals A1 and A2 as shown in Figure 9 on page 21. For enclosed models, connect a DC motor to terminals 5 (A1) and 4 (A2) as shown in Figure 10 on page 22. Ensure that the motor voltage rating is consistent with the drive's output voltage.

### Speed Adjust Potentiometer


For chassis models, use a 10K ohm, 1/4 W potentiometer for speed control. Connect the counter-clockwise end of the potentiometer to S1, the wiper to S2, and the clockwise end to S3. If the potentiometer works inversely of the desired functionality (e.g. to increase motor speed you must turn the potentiometer counterclockwise), power off the drive and swap the S1 and S3 connections. Refer to Figure 9 on page 21.

For enclosed models, the speed adjust potentiometer is factory installed and prewired.

### Analog Input Signal

Instead of using a speed adjust potentiometer, the drive may be wired to follow an analog input voltage signal that is isolated from earth ground (Figure 8). Connect the signal common (–) to S1. Connect the signal reference (+) to S2. Make no connection to S3. A potentiometer can be used to scale the analog input voltage. An interface device, such as Minarik Drives model PCM4, may be used to scale and isolate an analog input voltage.

An analog input voltage range of 0–2.5 VDC is required to produce an armature voltage range of 0–90 VDC with 115 VAC line voltage or 0–180 VDC with 230 VAC line voltage.



### Figure 8. Analog Input Signal Connections




Figure 9. Chassis Drive Connections




Figure 10. Cased Drive Connections

## Section 4. Operation



Change voltage switch settings only when the drive is disconnected from AC line voltage. Make sure both switches are set to their correct position. If the switches are improperly set to a lower voltage position, the motor will not run at full voltage and may cause damage to the transformer. If the switches are improperly set to a higher voltage position, the motor will overspeed, which may cause motor damage, or result in bodily injury or loss of life.

Dangerous voltages exist on the drive when it is powered. BE ALERT. High voltages can cause serious or fatal injury. For your safety, use personal protective equipment (PPE) when operating this drive.

If the motor or drive does not perform as described, disconnect the AC line voltage immediately. Refer to the Troubleshooting section, page 51, for further assistance.

### Before Applying Power

1. Verify that no foreign conductive material is present on the printed circuit board.
2. Ensure that all switches and jumpers are properly set.

## Select Switches

### Input Voltage Select (SW501, SW502)

Set the input voltage select switches SW501 and SW502 to either 115 or 230 to match the AC line voltage. See Figure 11.

### Armature Voltage Select (SW503)

Set the armature voltage select switch SW503 to either 90 or 180 to match the maximum armature voltage. See Figure 11.




Figure 11. Select Switches

## Operation Modes



MAX SPD and TORQUE trim pots must be recalibrated everytime the drive is switched between SPEED and TORQUE mode.

### Speed Mode

In Speed Mode, the external potentiometer adjusts the speed (voltage) of the motor. The on-board MAX SPD trim pot sets the maximum speed of the motor. The on-board TORQUE trim pot sets the maximum torque available. The drive comes factory calibrated for speed mode.

To run the drive in Speed Mode, jumper pins 2 & 3 and pins 4 & 5 on J503. See Figure 12 and Figure 13 on page 26 for jumper settings and location.

### Torque Mode

In Torque Mode, the external potentiometer adjusts the torque (current) of the motor. The on-board MAX SPD trim pot sets the maximum torque available. The on-board TORQUE trim pot sets the maximum speed of the motor.

To run the drive in Torque Mode, jumper pins 1 & 2 and pins 3 & 4 on J503.

See Figure 12 and Figure 13 on page 26 for jumper settings and location.




Figure 12. J503 SPEED/TORQUE Jumper Settings




Figure 13. J503 SPEED/TORQUE Jumper Location

## **Startup**

### **MM23002D and MM23012D**

1. Turn the speed adjust potentiometer full counterclockwise (CCW) or set the input voltage signal to minimum.
2. Apply AC line voltage.
3. Slowly advance the speed adjust potentiometer clockwise (CW) or increase the input voltage signal. The motor slowly accelerates as the potentiometer is turned CW or as the input voltage signal is increased. Continue until the desired speed is reached.
4. Remove AC line voltage from the drive to coast the motor to a stop.

### **MM23102D, MM23112D, MM23402D, and MM23412D**

1. Turn the speed adjust potentiometer to "0" (full CCW) or set the input voltage signal to minimum.
2. Set the POWER switch to the ON position.
3. Slowly advance the speed adjust potentiometer clockwise (CW) or increase the input voltage signal. The motor slowly accelerates as the potentiometer is turned CW or as the input voltage signal is increased. Continue until the desired speed is reached.
4. Set the POWER switch to the OFF position to coast the motor to a stop.

### MM23202D and MM23212D



Do not change the FORWARD / REVERSE switch while the motor is running. The motor must come to a complete stop before reversing. Changing motor direction before allowing the motor to completely stop will cause excessively high current to flow in the armature circuit, and will damage the drive and/or motor.

1. Set the RUN/BRAKE switch to the BRAKE position.
2. Turn the speed adjust potentiometer to "0" (full CCW) or set the input voltage signal to minimum.
3. Set the POWER switch to the ON position.
4. Set the FORWARD/REVERSE switch to the desired direction of rotation.
5. Set the RUN/BRAKE switch to the RUN position.
6. Slowly advance the speed adjust potentiometer clockwise (CW) or increase the input voltage signal. The motor slowly accelerates as the potentiometer is turned CW or as the input voltage signal is increased. Continue until the desired speed is reached.
7. To reverse direction:
  - a. Set the RUN/BRAKE switch to the BRAKE position.
  - b. **Wait for the motor to come to a complete stop.**
  - c. Set the FORWARD/REVERSE switch to the desired direction of rotation.
  - d. Set the RUN/BRAKE switch to the RUN position.
8. To brake the motor, set the RUN/BRAKE switch to the BRAKE position. To coast the motor to a stop, set the POWER switch to the OFF position.

## Starting and Stopping Methods



Dynamic braking, coasting to a stop, or decelerating to minimum speed is recommended for frequent starts and stops. Do not use any of these methods for emergency stopping. They may not stop a drive that is malfunctioning. Removing AC line power (both lines) is the only acceptable method for emergency stopping.

For this reason, Minarik Drives strongly recommends installing an emergency stop switch on both AC line inputs (see Figure 9 on page 21).

Frequent starting and stopping can produce high torque. This may cause damage to motors, especially gearmotors that are not properly sized for the application.

### Automatic Restart Upon Power Restoration

All drives automatically run to set speed when power is applied and the inhibit is not active.

### Line Starting and Stopping

Line starting and stopping (applying and removing AC line voltage) is recommended for infrequent starting and stopping of a drive only. When AC line voltage is applied to the drive, the motor accelerates to the speed set by the speed adjust potentiometer or analog signal. When AC line voltage is removed, the motor coasts to a stop.

### Dynamic Braking



Wait for the motor to completely stop before switching back to RUN. This will prevent high armature currents from damaging the motor or drive.

Dynamic braking may be used to rapidly stop a motor (Figure 14 on page 31). For the RUN/BRAKE switch, use a two pole, two position switch rated for at least the armature voltage rating and 150% of the armature current rating. For the dynamic brake resistor, use a 40 watt minimum, high power, wirewound resistor.

Sizing the dynamic brake resistor depends on load inertia, motor voltage, and braking time. Use a lower-value, higher-wattage dynamic brake resistor to stop a motor more rapidly. Refer to Table 3 on page 31 for recommended dynamic brake resistor sizes.

**Note:** Models MM23202D and MM23212D incorporate dynamic braking in their designs.

Table 3. Minimum Recommended Dynamic Brake Resistor Values

<i>Motor Armature Voltage</i>	<i>Dynamic Brake Resistor Value</i>
90 VDC	15 ohms
180 VDC	30 ohms

For motors rated 1/17 horsepower and lower, a brake resistor is not necessary since the armature resistance is high enough to stop the motor without demagnetization. Replace the dynamic brake with 12-gauge wire.




Figure 14. Dynamic Brake Wiring with Inhibit set to “Inhibit Zero Mode”

## Inhibit Terminals

Activate the INHIBIT to coast the motor to minimum or zero speed (see Figure 15 for INHIBIT terminal location). Deactivate the INHIBIT terminals to accelerate the motor to set speed. See Figure 16 on page 34 for jumper J501 and J502 configuration, which determines if the INHIBIT is normally open or normally closed to run. The INHIBIT function will work the same way in Speed or Torque Mode.

Twist inhibit wires and separate them from power-carrying wires or sources of electrical noise. Use shielded cable if the inhibit wires are longer than 18 inches (46 cm). If shielded cable is used, ground only one end of the shield to earth ground. Do not ground both ends of the shield.

Minarik Drives offers two accessory plug harnesses for connecting to the INHIBIT terminals: part number 201-0024 [plug with 18 in. (46 cm) leads]; and part number 201-0079 [plug with 36 in. (91 cm) leads].
















Figure 15. Inhibit Terminals

CONFIGURATION	DRIVE RESPONSE
<p>INHIBIT TERMINALS S0502</p>  <p>TERMINALS SHORTED</p> <p>J502</p>  <p>J501</p> 	<p><b>INHIBIT MIN MODE</b> INHIBITS TO MINIMUM SPEED WHEN INHIBIT TERMINALS ARE SHORTED</p>
<p>INHIBIT TERMINALS S0502</p>  <p>TERMINALS SHORTED</p> <p>J502</p>  <p>J501</p> 	<p><b>INHIBIT ZERO MODE</b> INHIBITS TO ZERO SPEED WHEN INHIBIT TERMINALS ARE SHORTED</p>
<p>INHIBIT TERMINALS S0502</p>  <p>TERMINALS OPENED</p> <p>J502</p>  <p>J501</p> 	<p><b>INVERT INHIBIT MIN MODE</b> INHIBITS TO MINIMUM SPEED WHEN INHIBIT TERMINALS ARE OPENED</p>
<p>INHIBIT TERMINALS S0502</p>  <p>TERMINALS OPENED</p> <p>J502</p>  <p>J501</p> 	<p><b>INVERT INHIBIT ZERO MODE</b> INHIBITS TO ZERO SPEED WHEN INHIBIT TERMINALS ARE OPENED</p>

NOTE: The MAX SPD and MIN SPD trim pots must be recalibrated everytime the inhibit mode (J501 or J502) jumpers are changed.

Figure 16. Inhibit Personality Configuration

## Decelerating to Minimum Speed

The switch shown in Figure 17 may be used to decelerate a motor to a minimum speed. Closing the switch between S1 and S2 decelerates the motor from set speed to a minimum speed determined by the MIN SPD trim pot setting. If the MIN SPD trim pot is set full CCW, the motor decelerates to zero speed when the switch between S1 and S2 is closed. The DECEL trim pot setting determines the rate at which the drive decelerates. By opening the switch, the motor accelerates to set speed at a rate determined by the ACCEL trim pot setting.




Figure 17. Run/Decelerate to Minimum Speed Switch

## Section 5. Calibration



Dangerous voltages exist on the drive when it is powered. When possible, disconnect the voltage input from the drive before adjusting the trim pots. If the trim pots must be adjusted with power applied, use insulated tools and the appropriate personal protection equipment. **BE ALERT.** High voltages can cause serious or fatal injury.

MM23xx2D series drives have user-adjustable trim pots. Each drive is factory calibrated to its maximum current rating. Readjust the calibration trim pot settings to accommodate lower current rated motors.

All adjustments increase with CW rotation, and decrease with CCW rotation. Use a non-metallic screwdriver for calibration. Each trim pot is identified on the printed circuit board.

### Minimum Speed (MIN SPD)

The MIN SPD setting determines the minimum motor speed when the speed adjust potentiometer or input voltage signal is set for minimum speed. It is factory set for zero speed.

To calibrate the MIN SPD:

1. Set the MIN SPD trim pot full CCW.
2. Set the speed adjust potentiometer or input voltage signal for minimum speed.
3. Adjust MIN SPD until the desired minimum speed is reached or is just at the threshold of rotation.

### Maximum Speed (MAX SPD)

The MAX SPD setting determines the maximum motor speed when the speed adjust potentiometer or input voltage signal is set for maximum speed.

To calibrate MAX SPD:

1. Set the MAX SPD trim pot full CCW.
2. Set the speed adjust potentiometer or input voltage signal for maximum speed.
3. Adjust MAX SPD until the desired maximum speed is reached.

**Note:** Check the MIN SPD and MAX SPD adjustments after recalibrating to verify that the motor runs at the desired minimum and maximum speed.

## Torque (TORQUE)



TORQUE should be set to 150% of motor nameplate current rating. Continuous operation beyond this rating may damage the motor. If you intend to operate beyond the rating, contact your Minarik Drives representative for assistance.

The TORQUE setting determines the maximum torque for accelerating and driving the motor. To calibrate TORQUE, refer to the recommended TORQUE settings in Figure 18 on page 39 or use the following procedure:

1. With the power disconnected from the drive, connect a DC ammeter in series with the armature.
2. Set the TORQUE trim pot to minimum (full CCW).
3. Set the speed adjust potentiometer full CW or input voltage signal to maximum speed.
4. Carefully lock the motor armature. Be sure that the motor is firmly mounted.
5. Apply line power. The motor should be stopped.
6. Slowly adjust the TORQUE trim pot CW until the armature current is 150% of motor rated armature current.
7. Turn the speed adjust potentiometer CCW or decrease the input voltage signal.
8. Remove line power.
9. Remove the stall from the motor.
10. Remove the ammeter in series with the motor armature if it is no longer needed.

### IR Compensation (IR COMP)

The IR COMP setting determines the degree to which motor speed is held constant as the motor load changes.

Use the following procedure to recalibrate the IR COMP setting:

1. Set the IR COMP trim pot to minimum (full CCW).
2. Increase the speed adjust potentiometer or input voltage signal until the motor runs at midspeed without load (for example, 900 RPM for an 1800 RPM motor). A handheld tachometer may be used to measure motor speed.
3. Load the motor armature to its full load armature current rating. The motor should slow down.
4. While keeping the load on the motor, rotate the IR COMP trim pot until the motor runs at the speed measured in step 2. If the motor oscillates (overcompensation), the IR COMP trim pot may be set too high (CW). Turn the IR COMP trim pot CCW to stabilize the motor.
5. Unload the motor.

See Figure 18 on page 39 for recommended IR COMP settings.

## MODELS MM23012D, MM23112D, MM23212D, MM23412D



## MODELS MM23002D, MM23102D, MM23202D, MM23402D



Figure 18. Recommended TORQUE and IR COMP Settings  
(actual settings may vary with each application)

### Acceleration (ACCEL)

The ACCEL setting determines the time the motor takes to ramp to a higher speed. See Specifications on page 1 for approximate acceleration times. ACCEL is factory set for the shortest acceleration time (full CCW).

To set the acceleration time:

1. Set the speed adjust potentiometer or input voltage signal for minimum speed. The motor should run at minimum speed.
2. Set the speed adjust potentiometer or input voltage signal for maximum speed. Measure the time it takes the motor to go from minimum to maximum speed.
3. If the time measured in step 2 is not the desired acceleration time, turn the ACCEL trim pot CW for a longer acceleration time or CCW for a shorter acceleration time. Repeat steps 1 through 2 until the acceleration time is correct.

### Deceleration (DECEL)

The DECEL setting determines the time the motor takes to ramp to a lower speed. See Specifications on page 1 for approximate deceleration times. DECEL is factory set for the shortest deceleration time (full CCW).

To set the deceleration time:

1. Set the speed adjust potentiometer or input voltage signal for maximum speed. The motor should run at maximum speed.
2. Set the speed adjust potentiometer or input voltage signal for minimum speed. Measure the time it takes the motor to go from maximum to minimum speed.
3. If the time measured in step 2 is not the desired deceleration time, turn the DECEL trim pot CW for a longer deceleration time or CCW for a shorter deceleration time. Repeat steps 1 through 2 until the deceleration time is correct.

## Torque Mode Calibration



MAX SPD and TORQUE trim pots must be recalibrated every time the drive is switched between Speed and Torque modes.

1. Disconnect power from the drive and connect a DC voltmeter across the armature.
2. Set the MAX SPD and TORQUE trim pots to the 12 o'clock position.
3. Set the external potentiometer or input voltage for maximum.
4. Apply line power.
5. Adjust the TORQUE trim pot so the motor is running at the motor's maximum rated input voltage (nameplate rating).
6. Remove line power and the DC voltmeter. Be sure the motor is firmly mounted. Connect a DC ammeter in series with the armature. Carefully lock the motor armature.
7. Apply line power.
8. With the external potentiometer set to full CW or with the input voltage signal set for maximum, slowly adjust the MAX SPD trim pot until the motor draws 100% of the motor's rated armature current (nameplate rating).
9. Remove the line power, the stall from motor, and the ammeter.

## Section 6.Application Notes

### Multiple Fixed Speeds

Replace the speed adjust potentiometer with a series of resistors with a total series resistance of 10K ohms (Figure 19). Add a single pole, multi-position switch with the correct number of positions for the desired number of fixed speeds.




Figure 19. Multiple Fixed Speeds

## Adjustable Speeds Using Potentiometers In Series

Replace the speed adjust potentiometer with a series of resistors with a total series resistance of 10K ohms (Figure 20). Add a single pole, multi-position switch with the correct number of positions for the desired number of fixed speeds.




Figure 20. Adjustable Speeds Using Potentiometers In Series

## Independent Adjustable Speeds

Replace the speed adjust potentiometer with a single pole, multi-position switch, and two or more potentiometers in parallel, with a total parallel resistance of 10K ohms. Figure 21 shows the connection of two independent speed adjust potentiometers that can be mounted at two separate operating stations.




Figure 21. Independent Adjustable Speeds

## RUN/JOG Switch - Inhibit Connection

Using a RUN/JOG switch is recommended in applications where quick stopping is not needed and frequent jogging is required. Use a single pole, two position switch for the RUN/JOG switch, and a single pole, normally closed, momentary operated pushbutton for the JOG pushbutton.

Connect the RUN/JOG switch and JOG pushbutton to the inhibit plug as shown in Figure 22. The motor coasts to a stop when the RUN/JOG switch is set to JOG. Press the JOG pushbutton to jog the motor. Return the RUN/JOG switch to RUN for normal operation.




Figure 22. RUN/JOG Switch - Connection to Inhibit Plug with Normally Open Inhibit set for Zero Mode

## RUN/JOG Switch - Potentiometer Connection

Connect the RUN/JOG switch and the JOG pushbutton as shown in Figure 23. When the RUN/JOG switch is set to JOG, the motor decelerates to minimum speed (minimum speed is determined by the MIN SPD trim pot setting). Press the JOG pushbutton to jog the motor. Return the RUN/JOG switch to RUN for normal operation.




Figure 23. RUN/JOG Switch - Connection to Speed Adjust Potentiometer

## Leader-Follower Application

In this application, use a PCM4 to monitor the speed of the leader motor (Figure 24). The PCM4 isolates the leader motor from the follower drive, and outputs a voltage proportional to the leader motor armature voltage. The follower drive uses this voltage reference to set the speed of the follower motor. An optional ratio potentiometer may be used to scale the PCM4 output voltage.




Figure 24. Leader-Follower Application

## Single Speed Potentiometer Control Of Multiple Drives

Multiple drives can be controlled with a single speed adjust potentiometer using a USIM-8 at the input of each drive to provide isolation (Figure 25). Optional ratio potentiometers can be used to scale the USIM-8 output voltage, allowing independent control of each drive.




Figure 25. Single Speed Potentiometer Control of Multiple Drives

## Reversing

A dynamic brake may be used when reversing the motor direction (Figure 26). Use a three pole, three position switch rated for at least the maximum DC armature voltage and maximum braking current. Wait for the motor to stop completely before switching it to either the forward or reverse direction. See the Dynamic braking section on page 31 for recommended dynamic brake resistor sizes.




Figure 26. Reversing Circuit Wiring

## Section 7. Diagnostic LEDs

MM23xx2D series drives are equipped with two diagnostic LEDs:

- **Power (POWER):** Green LED lights whenever AC line voltage is applied to the drive.
- **Current Limit (TQ LIMIT):** Red LED lights whenever the drive reaches current limit.




Figure 27. Diagnostic LED Locations

## Section 8. Troubleshooting



Dangerous voltages exist on the drive when it is powered. When possible, disconnect the drive while troubleshooting. High voltages can cause serious or fatal injury.

### Before Troubleshooting

Perform the following steps before starting any procedure in this section:

1. Disconnect AC line voltage from the drive.
2. Check the drive closely for damaged components.
3. Check that no conductive or other foreign material has become lodged on the printed circuit board.
4. Verify that every connection is correct and in good condition.
5. Verify that there are no short circuits or grounded connections.
6. Check that the selection switch settings are correctly set.
7. Check that the drive's rated armature is consistent with the motor ratings.

For additional assistance, contact your local Minarik Drives distributor or the factory direct:

(800) MINARIK or FAX: (800) 394-6334

PROBLEM	POSSIBLE CAUSE	SUGGESTED SOLUTIONS
<b>Line fuse blows.</b>	1. Line fuse is the wrong size.	1. Check that the line fuse is correct for the motor size.
	2. Motor cable or armature is shorted to ground.	2. Check motor cable and armature for shorts.
	3. Nuisance tripping caused by a combination of ambient conditions and high-current spikes (i.e. reversing).	3. Add a blower to cool the drive components, decrease TORQUE settings, resize motor and drive for actual load demand, or check for incorrectly aligned mechanical components or "jams". See page 38 for information on adjusting the TORQUE trim pot.
<b>Line fuse does not blow, but the motor does not run.</b>	1. Speed adjust potentiometer or input voltage signal is set to zero speed.	1. Increase the speed adjust potentiometer setting or input voltage signal.
	2. INHIBIT mode is active.	2. Remove the short from the INHIBIT terminals or add a short to INHIBIT terminals if INHIBIT mode is set to INVERTED.
	3. S2 is shorted to S1.	3. Remove the short.
	4. Drive is in current limit.	4. Verify that the motor is not jammed. Increase TORQUE setting if set too low.
	5. Drive is not receiving AC line voltage.	5. Apply AC line voltage.
	6. Motor is not connected.	6. Remove power. Connect the motor to A1 and A2. Reapply power.

PROBLEM	POSSIBLE CAUSE	SUGGESTED SOLUTIONS
<b>Motor does not stop when the speed adjust potentiometer is full CCW.</b>	1. MIN SPD is set too high.	1. Calibrate MIN SPD.
<b>Motor runs in the opposite direction</b>	1. Motor connections to A1 and A2 are reversed.	1. Remove power. Reverse connections to A1 and A2. Reapply power.
<b>Motor runs too fast.</b>	1. MAX SPD is set too high.	1. Calibrate MAX SPD.
<b>Motor will not reach the desired speed.</b>	1. MAX SPD setting is too low.	1. Increase MAX SPD setting.
	2. IR COMP setting is too low.	2. Increase IR COMP setting.
	3. TORQUE setting is too low.	3. Increase TORQUE setting.
	4. Motor is overloaded.	4. Check motor load. Resize the motor and drive if necessary.
<b>Motor pulsates or surges under load.</b>	1. IR COMP is set too high.	1. Adjust the IR COMP setting slightly CCW until the motor speed stabilizes.
	2. Motor bouncing in and out of current limit.	2. Make sure motor is not undersized for load; adjust TORQUE trim pot CW.

## Section 9. Block Diagrams




Figure 28. MM23xxD Series Block Diagram




Figure 29. MM23102D, MM23112D, MM23402D, and MM23412D  
Terminal Block Connections




Figure 30. MM23202D and MM23212D Terminal Block Connections

## Section 10. Accessories & Replacement Parts

### Displays

Closed Loop.....	DLC600
Open Loop.....	VT-8

### Heat Sinks

Chassis .....	223-0159
NEMA 1 .....	223-0174

### Kits

#### Potentiometer & Connector

Pot Kit .....	202-0031
---------------	----------

#### Fuse

1.5 - 5 Amp Fuse Kit.....	050-0066
1 - 8 Amp Fuse Kit with Pico Fuse.....	050-0068
3 - 8 Amp Fuse Kit with Pico Fuse.....	050-0069
5 - 15 Amp Fuse Kit.....	050-0071

#### Wiring

Inhibit Plug (18 in. leads).....	201-0024
Inhibit Plug (36 in. leads).....	201-0079

### Logic Cards

#### Current Sensing

5 Amps.....	CSC1-5
20 amps .....	CSC1-20

#### Isolation Cards

Unidirectional, 8 outputs.....	USIM-8
Bidirectional, 1 output.....	PCM4

### Section 11. CE Compliance

---

Minarik Drives hereby certifies that its MM23xx2D series drives have been approved to bear the “CE” mark provided the conditions of approval have been met by the end user.

The MM23xx2D series has been tested to the following test specifications:

Emissions: EN 61800-3:2005 (Section 5.3)

CISPR 11:2003

Immunity: EN 61800-3:2005 (Section 6.3 and 6.4)

EN 61000-4:2009

EN 61000-4-3:2006/A2:2010

EN61000-4-4:2004+A1:2010

EN 61000-4-5:2006

EN 61000-4-6:2007

1. The MM23xx2D series unit must be in a single-point grounded enclosure.
2. All cables use shielded wires.
3. The AC line requires a Corcom line filter 20VV1.

## Unconditional Warranty

---

### A. Warranty

Minarik Drives warrants that its products will be free from defects in workmanship and material for twelve (12) months or 3000 hours, whichever comes first, from date of manufacture thereof. Within this warranty period, Minarik Drives will repair or replace, at its sole discretion, such products that are returned to Minarik Drives, 14300 De La Tour Drive, South Beloit, Illinois 61080 USA.

This warranty applies only to standard catalog products, and does not apply to specials. Any returns of special controls will be evaluated on a case-by-case basis. Minarik Drives is not responsible for removal, installation, or any other incidental expenses incurred in shipping the product to and from the repair point.

### B. Disclaimer

The provisions of Paragraph A are Minarik Drives's sole obligation and exclude all other warranties of merchantability for use, expressed or implied. Minarik Drives further disclaims any responsibility whatsoever to the customer or to any other person for injury to the person or damage or loss of property of value caused by any product that has been subject to misuse, negligence, or accident, or misapplied or modified by unauthorized persons or improperly installed.

### C. Limitations of Liability

In the event of any claim for breach of any of Minarik Drives's obligations, whether expressed or implied, and particularly of any other claim or breach of warranty contained in Paragraph A, or of any other warranties, expressed or implied, or claim of liability that might, despite Paragraph B, be decided against Minarik Drives by lawful authority, Minarik Drives shall under no circumstances be liable for any consequential damages, losses, or expenses arising in connection with the use of, or inability to use, Minarik Drives's product for any purpose whatsoever.

An adjustment made under warranty does not void the warranty, nor does it imply an extension of the original 12-month warranty period. Products serviced and/or parts replaced on a no-charge basis during the warranty period carry the unexpired portion of the original warranty only.

If for any reason any of the foregoing provisions shall be ineffective, Minarik Drives's liability for damages arising out of its manufacture or sale of equipment, or use thereof, whether such liability is based on warranty, contract, negligence, strict liability in tort, or otherwise, shall not in any event exceed the full purchase price of such equipment.

Any action against Minarik Drives based upon any liability or obligation arising hereunder or under any law applicable to the sale of equipment or the use thereof, must be commenced within one year after the cause of such action arises.



[www.minarikdrives.com](http://www.minarikdrives.com)  
14300 DE LA TOUR DRIVE  
SOUTH BELOIT, IL 61080  
(800) MINARIK

250-0382 Rev 6